

# Two-sizes-in-one means economy, flexibility and comfort!

MULTIMAX changes the shape of hearing protection. It is a uniquely designed two-sizes-in-one ear plug. You have the choice of which tip fits and works best and is most comfortable for you. This dual usage feature eliminates the need to buy several products for different sized ear canals, making purchasing and stocking much simpler!

*MULTIMAX* has our trademark smooth, soil-resistant skin features and attenuation effectiveness.

## Selectivity

*MULTIMAX* is a unique dual-usage two-sizes-in-one ear plug.

## Unique design and shape

The unique design of *MULTIMAX* ear plugs provides easy and comfortable insertion in all size ear canals.

## Easy inventory control

Two-sizes-in-one makes inventory control easy.

### **NRR 31**

MULTIMAX has a very high attenuation rating.



# Disposable Ear Plug fitting instructions

- Before fitting any ear plugs, make sure your hands are clean.
- ► When using the MULTIMAX, try the larger, coral end first.
- 1. Hold the ear plug between your thumb and forefinger. Roll and compress the entire ear plug to a small, creasefree cylinder.
- 2. While still rolling, use your other hand to reach over your head and pull up and back on your outer ear. This straightens the ear canal, making way for a snug
- 3. Insert the ear plug and hold for 20 to 30 seconds. This allows the ear plug to expand and fill your ear canal.
- ► Test the fit. In a noisy environment, and with earplugs inserted, cup both hands over your ears and release. You should not notice a significant difference in the noise level. If the noise seems to lessen when your hands are cupped over your ears, your ear plugs are probably not fitted properly. Remove and refit following instruc-
- Always remove ear plugs slowly, twisting them to break the seal. If you remove them too quickly, you could damage your ear drum.
- ► Foam ear plugs are disposable and not intended for re-use.



# Packaging options

MultiMax ear plugs, in high visibility coral and yellow colors, are packed in individual poly or paper bags.

The Leight Ear Plug Dispenser is a permanent protection center that is easy to use, and buying ear plugs in bulk means you're not paying for unnecessary packaging.



#### **Attenuation Data**

## **MULTI-MAX**

ATTENUATION - USA (ANSI)									
TESTED ACCORDING TO ANSI S12.6-1974 NRR 31dB									
Frequency (Hz)	125	250	500	1000	2000	3150	4000	6300	8000
Mean Attenuation dB(A)	30.9	32.4	33.9	34.9	36.5	46.1	47.1	50.9	52.1
Standard Deviation dB(A)	2.1	2.5	2.7	1.9	1.9	3.3	2.6	2.7	2.5

NRR 31 SNR 35 CE SLC<sub>80</sub> 26.0 CSA A(L)

## Ordering Information

Without cord. MM-1

packed in individual poly bags

Case of 2,000 pair

(10 self-dispensing boxes/200

pair per box)

MM-1-PB Without cord,

> packed in biodegradable, repulpable paper bags Case of 2,000 pair

(10 self-dispensing boxes/200

pair per box)

MM-1-D Dispenser Box

> Bulk packed for use in the Howard Leight dispenser ONLY

Case of 2,000 pair (4 dispenser boxes/500

pair per box)



#### HOWARD LEIGHT INDUSTRIES A Division of Bacou USA Safety, Inc.

7828 Waterville Road San Diego, CA 92173 Tel (800) 327-1110 Fax (800) 322-1330 www.howardleight.com









